

## TCX-LPI Wiring Instructions: Programmable Loop Powered LED Display

1. Unscrew the window cover.
2. Remove the display by unscrewing the two screws on the back of the display, while keeping all wires intact.
3. Unplug the green connector from the back of the display.
4. Feed your loop power wires into the head. Follow the wiring diagram below the green plug on the back of the display and attach your loop + and - wires to the unused + and - terminals on the green plug.
5. Reconnect the green plug to the back of the display.
6. Reassemble the unit.

