

Accessories

Terminal Blocks



2 pole **TCX001T2**



3 pole **TCX001T3**



4 pole **TCX001T4**



6 pole **TCX001T6**

Plugs & Jacks

Thermocouples



Std. Male Plug
TCX*_PLUG



Std. Female Jack
TCX*_JACK

TCXSTDCLA = clamp set
for std. plug/jack



Mini Male Plug
TCX*_PLUG MINI



Mini Female Jack
TCX*_JACK MINI

TCXMINCLA = clamp set
for Mini plug/jack

* Insert thermocouple type (J,K,T,E)

Heads



TCX006_*

* = Enter letter code from p. TC1 (A)

Spring Loaded Kit



TCXBSL22

In-Head Transmitters



TCXT4-X = 4-20mA transmitter

TCXT4-R = 4-20mA Hart transmitter